


WIRING DIAGRAM



SWITCH CONTINUITY

IGNITION SWITCH						
	BAT	IG	ACC	TL1	TL2	P
OFF						
ACC						
ON						
P						
COLOR	R	Bk	LG/Bk	Br/W	Br/W	Br

STARTER SWITCH				
	HL1	HL2	IG	ST
FREE				
PUSH				
COLOR	Bk/R	B/W	Bk	Y/R

ENGINE STOP SWITCH		
	KB	KW
OFF		
RUN		
OFF		
COLOR	Bk	Bk/W

TURN SIGNAL SWITCH						
	R	W	R	L	P	PL
R						
N						
L						
COLOR	Gr	LB	O	Br/W	LB/W	O/W




DIMMER SWITCH			
	HL	Lo	Hi
Lo			
(N)			
Hi			
COLOR	B/W	W	B

HORN SWITCH		
	HO	E
FREE		
PUSH		
COLOR	LG	G

Br	Brown	Y	Yellow
Bk	Black	B	Blue
W	White	Gr	Grey
LG	Light Green	LB	Light Blue
R	Red	O	Orange
G	Green	P	Pink

0030Z—MA2—6700

GENERAL INFORMATION

CABLE & HARNESS ROUTING

DETAIL (B)

DETAIL (A)
